

TWT Remote Controller

Interface

Remote Control	Rs232 or Rs422 (setting through the menu) through DB9-F
TWT1 Serial Remote Control	Rs232 or Rs422 (depends on TWT) through DB9-F Allows to monitor the functionality of the device (TWT1) and to find the alarm caused by incorrect working of the TWT and the set-up).
TWT2 Serial Remote Control	Rs232 or Rs422 (depends on TWT) through DB9-F Allows to monitor the functionality of the device (TWT2) and to find the alarm caused by incorrect working of the TWT and the set-up).

Mechanical Specification

Primary power requirements	230V AC \pm 10%, 50Hz to 60Hz, 40VA max
Mechanical construction	1U 19" standard rack, 350mm deep
Weight	2Kg
Temperature	0°C to 50°C operating -40°C to 85°C storage
Relative humidity	0 to 90% operating 0 to 95% storage
MTBF	80000 h

Model Type: **TRC0003A**

Antech Spa

San Giovanni La Punta
Catania (Italy)
Tel/fax: +39 095 741.74.00
+39 095 751.37.99
www.antech.it
info@antech.it

ETNATEL: www.etnatel.it
info@etnatel.it.

TWT Remote Controller
TRC0003A